

FIXTURES MUST BE INSTALLED ACCORDING TO LOCAL CODES AND N.E.C. BY A QUALIFIED ELECTRICIAN.
MAKE SURE ALL POWER IS DISCONNECTED PRIOR TO INSTALLATION.

CORD MOUNT WITH CEILING CANOPY

1. Insert pre-wired LED module with adapter into fixture. (pre-wired LED module and assembled to the adapter) fig.1
2. Slip through gasket over cord then the cover nut. IF the "O" ring is included make sure "O" ring is seated properly inside the groove of the cover nut. fig.1
3. Attach cover nut to adapter and gasket. (cover nut is reverse thread)
4. Tighten the cover nut firmly.
5. Cut the cord to the desired length and slip the canopy with cord grip (attached), bracket and cord with supplied cable tie. Fig. 2
6. Make wiring connection, (wiring diagram Fig. 3), and screw the bracket to the electrical box.
7. Secure the canopy to the bracket with the supplied screws.

