

READ PRIOR TO ATTEMPTING INSTALLATION
ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION
INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN

MULTIPLE TRIMLESS REMODEL INSTALLATION STEPS:
NOTE: BEFORE PROCEEDING, MAKE SURE POWER IS DISCONNECTED.

1. Trace the cut hole using the plaster frame as a template.
2. Cut hole with a drywall saw.
3. Plaster the inside top perimeter of the cut hole.
4. Install the plaster frame securely into the cut hole.
5. Plaster the ioutside of the cut hole plaster frame. Allow plaster to dry.
6. a. Screw aircraft cable into the ceiling joist to support the fixture during installation.
 b. Adjust the mounting bracket.*
 c. Wire the fixture.
 d. Insert the fixture into the opening.*
 e. Instal LEDs

* For 1 row x 1 lamp configuration, attach only 1 mounting bracket before inserting fixture into the opening, then finish by attaching the second mounting bracket, wire the fixture and install the bulbs.
IMPORTANT: Aircraft cable provided for safety and installation aid.

