

RECESSED MOUNT INSTALLATION INSTRUCTIONS

1. Lift the all mounting clip on the edge of panel
2. Turn the mounting clip head
3. Connect wires as shown in electrical schematic diagram
4. Check the clips well fasten to T-BAR (Main/Cross ceiling tee)

