



14135 INSTALLATION INSTRUCTIONS FOR: RECESSED MRI LED DOWNLIGHT

Please read all instructions prior to installation and keep for future reference!

1. Check if the local voltage range corresponds with the working voltage of the fixture. Use min. 75°C supply.
2. Use only UL (or other NRTL) approved wire for input/output connections.
3. Make sure LEDs and drivers are cool to touch when performing maintenance.
4. Do not install in a hazardous atmosphere, except where the ambient temperature does not exceed the rated operating temperature of the fixture.
5. Keep tightly closed when in operation
6. The grounding and bonding of the overall system shall be done in accordance with NEC Article 600 and local codes.

**14079 INSTALLATION INSTRUCTIONS FOR: LOW-PROFILE LED TROFFER LIGHT
AND LOW-PROFILE WET-LOCATION LED TROFFER LIGHT**

WARNING:



RISK OF FIRE AND ELECTRICAL SHOCK. FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY IN ACCORDANCE WITH NATIONAL, LOCAL BUILDING AND ELECTRICAL CODES. DISCONNECT POWER AT ELECTRICAL PANEL BEFORE SERVICING.

14079 INSTALLATION INSTRUCTIONS FOR: LOW-PROFILE LED TROFFER LIGHT AND LOW-PROFILE WET-LOCATION LED TROFFER LIGHT

TOOL(S) NEEDED:

Cordless drill and an elbow or L-shape adapter with Philips Insert Bit extension.

