

1. Remove the mounting plate by unscrewing the black screws from both sides of the fixture. Unscrew the two screws from the back plate of the fixture. Attach the mounting plate to the outlet box using two mounting screws.
2. Slide the glass through the bracket at the base of the fixture until it fits. Attach the glass by using two screws on the back plate of the fixture. Choose needed color temperature by adjusting switch position. Connect the wires: Black to Black, White to White, Ground to Ground. Secure the connection with wire nuts.
3. Attach the fixture to the mounting plate using two black screws on both sides. Before tightening the screws, try to fit the fixture to ensure the appropriate holes match. For outdoor locations it is recommended to use silicone (not included) shown in the picture below.

