

INSTALLATION INSTRUCTIONS

WARNING:




RISK OF FIRE AND ELECTRICAL SHOCK. FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY IN ACCORDANCE WITH NATIONAL, LOCAL BUILDING AND ELECTRICAL CODES. DISCONNECT POWER AT ELECTRICAL PANEL BEFORE SERVICING.


PLEASE READ ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION

To reduce the risk of death, electric shock, personal injury, property damage, or fire:


- Installation and service must be performed by qualified personnel familiar with the product's construction, operation, and associated hazards.
- Carefully read all instructions before installing, servicing, or replacing this fixture or its components.
- These instructions do not address every possible installation or maintenance scenario. If you encounter an unfamiliar situation or need additional guidance, please contact Alcon Lighting for support.




Wire wall switch to driver and junction box.




Drill holes for power cord and to mount to surface.




Mount LED tape to channel and wire channel.
(LED Tape sold separately)



Snap in lens.




Mounting for cable kit can slide anywhere along channel.




Screw end caps to channel.

Joining 2 Channels (Joiner sold separately)



Add Joiner accessory in raceway on top of channel to ensure proper alignment of channels.



Connect next channel to Joiner accessory and align.