

INSTALLATION AND REMOVAL

INSTRUCTIONS

1. Turn off power before beginning installation.
2. Use cog and slider to put the contact head adapter to unlock position and insert into the track. (Figure 1)
3. Make sure the polarity lines on both track and fixture are aligned.
4. Push the fixture straight into track, and put contact head adapter to lock position. (Figure 2)
5. To aim, rotate fixture horizontally from adapter and vertically from head.

REMOVAL INSTRUCTIONS

1. To remove, set contact head adapter to unlock position and remove from track.

