

INSTALLATION INSTRUCTIONS

1. Remove the lens from the fixture body. Choose needed color temperature by adjusting the switch position.
2. Attach the crossbar to the outlet box using mounting screws. Connect the wires: Black to Black, White to White, Green to Green. Secure the connection with wire nuts.
3. Place the fixture body over the outlet box onto the Mounting nipple and adjust it by tightening inward or out from the mounting bracket. Secure the fixture body position with cap nut. Reattach the lens to the fixture body using 4 screws. For outdoor locations it is recommended to use silicone (not included).

