


12100-20 | 12100-40 - INSTALLATION INSTRUCTIONS FOR SURFACE MOUNT

WARNING:

RISK OF FIRE AND ELECTRICAL SHOCK. FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY IN ACCORDANCE WITH NATIONAL, LOCAL BUILDING AND ELECTRICAL CODES. DISCONNECT POWER AT ELECTRICAL PANEL BEFORE SERVICING.



Specifications: 12100-20

Width: 2.5 (64) Depth: 4 (101)

All dimensions are in inches (millimeters).

Specifications: 12100-40

Width: 4 (101) Depth: 4 (101)

All dimensions are in inches (millimeters).


PART LIST

A: SNAP-IN Lens


D: Self-drilling anchor screw

B: LED module plate C: BX cable connector E: Washer F: J-box


G: Screws




Remove SNAP-IN lens (A).



Remove LED module plate (B).




Align fixture to ceiling to mark holes and locate J-box (F).




Refer to [4A, 4B] on the last page for detailed installation instructions.




12100-20 | 12100-40 - INSTALLATION INSTRUCTIONS FOR SURFACE MOUNT




Knockout hole for BX cables(C) and make wire connection to Fixture wires.



Screw fixture to ceiling using Self-Drilling Spiral Anchors(D) with washer(E).



Install LED module plate.



Close SNAP-IN Lens.




12100-20 | 12100-40 - INSTALLATION INSTRUCTIONS FOR SURFACE MOUNT


CONTINUOUS ROW

TOOL(S) NEEDED:


Option 1) Cordless drill and an elbow or L-shape adapter with Philips Insert Bit extension.

Option 2) Flexible Screwdriver with Philips Insert Bit.





Align all continuous fixtures to ceiling to mark holes and locate J-box(F).



- 1) Make wiring connection from each fixture power supply wires together.
- 2) Align fixtures and screw together with 4 screws(G).

