

## Installation Diagram


These instructions should be read carefully and retained after installation for further reference and maintenance.

### SAFETY:


1. Please read the specification first, to make sure the service environment matches the condition in the specification before using.
2. Make sure the switch of product is off before connecting to the power supply to prevent electric shock.
3. Operation against rules of product is off before connect to the power supply to your personal safety.
4. Dangerous high voltage, Non-professionals are not allowed to maintain the products.
5. If the exterior flexible cable is damaged, it must exchange by the supplier, agent or other similar qualified personnel.

### WARNING:


1. Ensure the luminaire is switched off & suitably cooled down before carrying out any maintenance work.
2. MIN 90 °C SUPPLY CONDUCTORS
3. SUITABLE FOR OPERATION IN AMBIENT NOT EXCEEDING 40°C
4. DRY LOCATIONS ONLY
5. All components in the luminaire shall not be replaced or serviced.




1. Take out the mounted bracket, mark the holes on the ceiling.




2. Drill the holes.




3. Push the rubber stopper to the holes.




4. Screw the mounted bracket to the ceiling.




5. Connect the wire to the electricity supply, make sure the L/N/GND connect correct.



6. Put the driver box to the hanging plate, make sure the holes on the both side are aligned, screw it.



7. Adjust the lifting rope and the wiring to the suitable length.



8. Done.