

SAFETY INFORMATION

- Disconnect power at the circuit breaker before installation or maintenance.
- Installation should be performed by a qualified electrician in accordance with local and national electrical codes.
 - Verify that the supply voltage matches the fixture rating (120V).

TOOLS & MATERIALS

- Measuring tape
- Level
- Hole saw or drywall saw
- Wire connectors
- Screwdriver
- Electrical tape

INSTALLATION STEPS

- 1. Prepare the Opening
- Cut a hole in the wall sized to fit the housing. Ensure the opening is clean and free of debris.

2. Power Connection

- Pull the electrical supply wires through the wall opening.
- Connect the fixture wires to the supply wires Secure all connections with wire connectors and wrap with electrical tape.


Mount the Housing
 Insert the fixture housing into the wall opening.


4. Install the Faceplate

- Align the faceplate with the housing and tighten the screws evenly.
- Make sure the lens is properly seated to maintain a weather-resistant seal.

5. Power On

- Restore power at the breaker.
 Test the fixture to ensure proper operation.





MAINTENANCE

- Periodically clean the lens with a soft cloth and mild soap solution.
- Check electrical connections annually for signs of wear or corrosion.