

**WARNING:** RISK OF FIRE AND ELECTRICAL SHOCK. FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY IN ACCORDANCE WITH NATIONAL, LOCAL BUILDING AND ELECTRICAL CODES. DISCONNECT POWER AT ELECTRICAL PANEL BEFORE SERVICING.

## 12213 INSTALLATION INSTRUCTIONS FOR: COLOR TEMPERATURE SWITCH LED GLASS GLOBE PENDANT LIGHT AND RGBW COLOR-CHANGING LED GLASS GLOBE PENDANT LIGHT



**Please read all instructions prior to installation and keep for future reference!**

1. Product to be installed by a qualified electrician.
2. Turn electricity off at main circuit breaker panel before beginning installation.
3. Glass parts are fragile, use care when handling lamp.

**Note:**

This product contains chemicals know to the State of California to cause cancer, birth defects and/or other reproductive harm. Thoroughly wash hands after installing, handling, cleaning, or otherwise touching.

- A. Fasten Mounting Strap (5) to Outlet Box (1) with Mounting Screws (6) from Outlet Box (1).
- B. Thread Nipple (7) and Green Ground Screw (10) into Mounting Strap (5).
- C. Slip Top Cap (13), Knurled Nut (15), Cap Nut (14) (OPEN SIDE DOWN), Cap Nut (9), Knurled Nut (12), and Canopy (8) down over Cord (4).
- D. Slip Cord (4) through Nipple (7) and tie a Knot (3) at height at which fixture is to hang.
- E. Connect Fixture Wires (11) to Supply Wires (2) as shown on wiring diagram.
- F. Raise Canopy (8) to ceiling and secure in place with Knurled Nut (12) and Capnut (9).
- G. Install Lamp (NOT FURNISHED).
- H. Slip Socket Assembly (16) through Glass Globe (17).
- I. Set Top Cap (13) down over Glass Globe (17) and secure in place with Knurled Nut (15) and Capnut (14).



## 12213 INSTALLATION INSTRUCTIONS FOR: COLOR TEMPERATURE SWITCH LED GLASS GLOBE PENDANT LIGHT AND RGBW COLOR-CHANGING LED GLASS GLOBE PENDANT LIGHT

### TOOL(S) NEEDED:

Cordless drill and an elbow or L-shape adapter with Philips Insert Bit extension.

